



# Quart Application

USES: Correct Adjacent Automotive Panels That Do Not Match

## Application:



**CB**  
Mix with Basecoat to Solve Color Matching Issues



**CBC**  
Panel Cleaner & Adhesion Promoter



**CBR**  
Chemicals Removers Products\*  
\*T-sprayed incorrect. ColorBalancer can be removed using ColorBalancer Remover (CBR). When finished, neutral with CBC Cleaner and recoat as necessary.



### STEP 1.) Clean

Area to be sprayed should be cleaned. Using ColorBalancer cleaner. It both cleans and chemically prepares the surface for adhesion without the need for sanding.



### STEP 2.) Mask

Areas surrounding area to be sprayed should be masked using 12" paper to reduce overspray.



### STEP 3.) Spray

Mix a small amount of remaining reduced basecoat to ColorBalancer per Tech Data Sheet. Hold spray gun 10"-12" from surface. Spray in light and even strokes, blending the edges of the two non matching panels, checking color match after each coat.



### STEP 4.) Hand Buff Edge (opt)

Allow 10 min. at 70°F for ColorBalancer to dry. If needed, hand-buff or lightly machine-buff with a foam pad the sprayed area to increase gloss and obtain a near-invisible blended edge.

**NOTE: ColorBalancer Does NOT Need to Be Clearcoated.**

## Examples:



Poor Color Match



Wrong Variant



Flip Incorrect



Clearcoat Changes Color

**KLINNE'S**  
**AUTO, INC.**

Available From: