

Spraymax® 2 part paint aerosol technology

Red release nozzle in outer cap to be used on valve at the bottom of can to evacuate hardener into paint from cylinder.

SprayMax valve in combination with new propellant technology.

Up take pipe and valve

Perforated top of cylinder to release hardener into paint from cylinder.

2 part paint

Separate hardener in cylinder (paint mix is 4:1 ratio.)

When ready to activate take red cap from outer cap, insert into the valve on bottom of can using limited force, activating hardener into paint.

