



Technical Bulletin

Uro Primer 1101S / 1104S / 1107S As A Primer - Sealer

Here is the recommendation for using the new URO primer 1101S /1104S / 1107S as primer-sealer. These recommendations will appear in the Tech Data Sheet shortly. Please follow these guidelines.

Mix ratio: 3 parts primer: 1 part activator: 2 parts reducer.

<u>Temperature</u>	<u>Activator</u>	<u>Reducer</u>
65-75F	7985S or 7995S	12375S
75-85F	7995S	12375S or 12385S
85-95F	7995S	12385S or 12395S
>95F	7995S	12395 S

KLINER'S – KEEPING YOU INFORMED

ALLENTOWN: 1-610-433-3203 / HAZLETON: 1-570-454-7616 / PHILLIPSBURG: 1-908-859-5911
POTTSVILLE: 1-570-622-4010 / READING: 1-610-929-4737 / SCRANTON: 1-570-344-8516
STROUDSBURG: 1-570-424-2253