



sikkens

All Plastic Primer Reducer Bulletin

With the recent return of cold weather throughout much of North America, Akzo Nobel Field Technical Staff has identified a visual concern regarding “ALL PLASTIC PRIMER REDUCER”.

The Reducer may become cloudy or separate when exposed to extreme cold temperatures. Although Analytical examination has produced “NO VARIATION” specific to anticipated coating performance, the following procedures are recommended during daily use of the material.

- Shake the Sikkens All Plastic Primer Reducer for 10-15 seconds prior to use.
- Avoid storing the Sikkens All Plastic Reducer under cold conditions for extended periods.
- Allow the Sikkens All Plastic Primer Reducer to come up to room temperature prior to use.

KLINER'S – KEEPING YOU INFORMED

ALLENTOWN: 1-610-433-3203 / HAZLETON: 1-570-454-7616 / PHILLIPSBURG: 1-908-859-5911
POTTSVILLE: 1-570-622-4010 / READING: 1-610-929-4737 / SCRANTON: 1-570-344-8516
STROUDSBURG: 1-570-424-2253