



Technical Service Bulletin

UTECH

Date: **04/20/2007**

No. **TSB 07-002 US & CAN**

Subject: **UTECH: Toner T277 Dosing order.**

Over time we received various complaints on incompatibility of the T277 (Magenta) toner in the Utech line. Various leads to resolve the problem have resulted in the following adaptation in the mixing order, when using T277, in order to prevent the incompatibility problem.

Instead of using the recommended mixing order from formulas retrieved from Mixit, please use the following steps:

**Combine all color components
(do **NOT** add the binder)**



Mix the color components well



Lastly, add the binder to make the product



Product is ready for use following the TDS

When introducing this process, a significant improvement was observed in the compatibility of the toner T277.

KLINÉ'S – KEEPING YOU INFORMED

**ALLENTOWN: 1-610-433-3203 / HAZLETON: 1-570-454-7616 / PHILLIPSBURG: 1-908-859-5911
POTTSVILLE: 1-570-622-4010 / READING: 1-610-929-4737 / SCRANTON: 1-570-344-8516
STROUDSBURG: 1-570-424-2253**